




Instructions for FRIXION

Dedicated FRIXION website : <http://www.frixion.jp/>

Do not use on official document, addresses or anything that should not be erased.

How to Use ● The ink colour will disappear when rubbed by the special rubber at the end of the pen body.



- Ink becomes transparent with frictional heat.
- No eraser residue.
- Erase and rewrite repeatedly.

Caution: Do not use on official document, addresses or anything that should not be erased.

- Do not expose to direct sunlight.
- Do not keep at the temperature over 60°C, or the ink will become colourless.
- At temperatures around -10°C or lower, the colour may recover and be visible again.
- Please do not use for writing on anything other than paper.
- Depending on the type of papers such as thermal paper or the characteristics of the printed paper, there could be cases where this erasure method cannot work properly.
- If rubbed by the rubber with stain, the surface of the paper would get dirty. Use the rubber after cleaning it off.
- Do not use on computer-scored answer sheets.

How to use FRIXION BALL KNOCK (Retractable Roller ball Pen) ● Click the clip




Chart of Refills (for items sold in Japan)

Product type	Product name	Art. No	Ball dia.	Refill for Available
Roller ball pen	FRIXION BALL 05	LFB-20EF	0.5 mm	LFBKRF-12EF-colour (except for Black, Red, Blue) (3 Refill set) LFBKRF-30EF-3B(Black), 3R(Red), 3L(Blue)
	FRIXION BALL KNOCK 05	LFBK-23EF		
	FRIXION BALL BIZ	LFB-150EF		
		LFBN-150EF		
	FRIXION BALL KNOCK BIZ	LFBK-2SEF		
	FRIXION BALL 07	LFB-20F	0.7 mm	LFBKRF-12F-colour (except for Black, Red, Blue) (3 Refill set) LFBKRF-30F-3B(Black), 3R(Red), 3L(Blue)
	FRIXION BALL KNOCK 07	LFBK-23F		
	FRIXION BALL SLIM 038	LFBS-18UF	0.38mm	LFBTRF-12UF-colour (except for Black, Red, Blue) (3 Refill set) LFBTRF-30UF-3B(Black), 3R(Red), 3L(Blue)
	FRIXION BALL SLIM BZ	LFBKS-1SUF		
	FRIXION POINT 04	LF-22P4	0.4 mm	(3 Refill set) LFRF-30P4-3B(Black), 3R(Red), 3L(Blue)
	FRIXION POINT BIZ	LF-2SP4/3SP4		
	FRIXION BALL ENPITSU	LFP-13F	0.7 mm	Non-Refillable

2 colour Roller ball pen	FRIXION BALL 2 BIZ	LFBT-3SUF	0.38mm	<2 Refill set> LFTRF-40UF-2B(Black), 2R(Red), 2L(Blue), 2C(Black,Red assorted)
			0.5 mm	<2 Refill set> LFTRF-40EF-2B(Black), 2R(Red), 2L(Blue), 2C(Black,Red assorted)
3 colour Roller ball pen	FRIXION BALL 3 038	LKFB-60UF	0.38mm	<3 Refill set> LFBTRF-30UF-3B(Black), 3R(Red), 3L(Blue), 3C(Black,Red,Blue assorted)
	FRIXION BALL 3 05	LKFB-60EF	0.5 mm	LFBTRF-12EF-G(Green) <3 Refill set> LFBTRF-30EF-3B(Black), 3R(Red), 3L(Blue), 3C(Black,Red,Blue assorted)
	FRIXION BALL 3 METAL	LKFB-150EF		
	FRIXION BALL 3 WOOD	LKFB-2SEF		
4 colour Roller ball pen	FRIXION BALL 4	LKFB-80EF	-	Non-Refillable
	FRIXION BALL 4 WOOD	LKFB-3SEF		
Spotlitter	FRIXION LIGHT	SFL-10SL		
Marker pen	FRIXION COLORS	SFC-10M		
Colored pencil	FRIXION IRO-ENPITSU	PF-10		

Chart of Rubber (for items sold in Japan)

Spare rubber parts are available only for the products listed below.

Product type	Product name	Art. No	Rubber for Available
Roller ball pen	FRIXION BALL BIZ	LFB-150EF	P-LFBRU-10B
	FRIXION POINT BIZ	LF-2SP4/3SP4	
3 colour Roller ball pen	FRIXION BALL 3 038	LKFB-60UF	LFBTRU-10-colour
	FRIXION BALL 3	LKFB-60EF	
	FRIXION BALL 3 METAL / WOOD	LKFB-150EF/2SEF	LFBTRU-23-colour
4 colour Roller ball pen	FRIXION BALL 4*	LKFB-80EF-BO, DL, BN, W	LFBFRU-10-BO, DL, BN, W
	FRIXION BALL 4*	LKFB-80EF-B	LFBTRU-10-B
	FRIXION BALL 4 WOOD	LKFB-3SEF	LFBFRU-23-colour

*Please note that spare rubber parts for FRIXION BALL 4 are different by pen body colour.

Products with eraser covers replaceable at point of repair

Product type	Product name	Art. No	Eraser cover replacement
Roller ball pen	FRIXION BALL BIZ	LFBN-150EF	Repairs carried out when product entrusted to repairer
	FRIXION BALL KNOCK BIZ	LFBK-2SEF	
	FRIXION BALL SLIM BIZ	LFBKS-1SUF	
2 colour Roller ball pen	FRIXION BALL 2 BIZ	LFBT-3SUF	

Remarks

- Do not use except for writing or drawing.
- Keep away from children.
- Do not write with the pen point upwards.

- To prevent ink leakage, do not shake hard.
- Always replace the cap / retract the tip after use.
- The stains on clothes may not wash off.

<http://www.pilot.co.jp/>