



Use and Care Guide MULTI FUNCTIONS PEN



<http://www.pilot.co.jp/>

PILOT 1+1, 2+1, 3+1 and 4+1 Series-a combination of mechanical pencil and ball point pen, all in one. Total of four kinds of PILOT 1+1, 2+1, 3+1 and 4+1 Series are available: Revolving, Retractable & Twist, Retractable & Button and Lever Slide.




Revolving (4+1 · 3+1 · 2+1 · 1+1)

● How to use the ball point pen

- (1) Turn the cap making the ball point come out.
- (2) To retract the ball point, turn the cap to the opposite direction.

● How to use the mechanical pencil

- (1) Press writing unit for the mechanical pencil comes out and is held in place by turning the cap clockwise. Press the cap to make the lead come out.
- (2) To retract the lead, press the lead onto the paper while pushing the cap down.
- (3) To retract the writing unit to its original position, turn the cap anticlockwise.
- (4) Screw the small cap off to get the eraser.






Retractable & Twist Type (3+1 · 2+1)

● How to use the ball point pen

- (1) While seeing the indication mark window, press the cap and a ball point of the colour of the identification mark will come out.
- (2) Twist the cap to the right while holding the barrel to retract the ball point.

● How to use the mechanical pencil

- (1) While seeing the mechanical pencil mark in the identification, press the cap and the writing unit for the mechanical pencil will come out. Then, press the cap some more to make the lead come out.
- (2) Twist the cap to the right while holding the barrel to return the writing unit to its original position, same as for the ball point pen.
- (3) Screw the small cap off to get the eraser.






Retractable & Button Type (2+1)

● How to use the ball point pen

- (1) While seeing the indication mark window (Black or Red), press the knob and a ball point of the colour of the identification mark will come out.
- (2) To retract the writing tip, press the button on clip.

● How to use the mechanical pencil

- (1) While seeing the mechanical pencil mark in the identification, press the knob and the writing unit for the mechanical pencil will come out. Then, press the knob some more to make the lead come out.
- (2) To retract the lead, press the lead onto the paper while pushing the knob down.
- (3) To retract the writing unit, press the button on clip.
- (4) Pull the knob get to the eraser.




Lever Slide Type (2+1 · 1+1)

● How to use the ball point pen


- (1) Slide the lever with identification mark (B or R) and a refill of the identification colour (B=Black or R=Red) comes out.
- (2) To retract the writing tip slide other lever.

● How to use the mechanical pencil


- (1) Slide the lever with identification mark (0.5) and the writing unit for the mechanical pencil comes out and is set in place. Press the cap to make the lead come out, and is set in place. Press the cap to make the lead come out.
- * In case of BEATNIC (Shaker mechanical pencil), just shake to make the lead come out.
- (2) To retract the lead, press the lead onto the paper while pushing the top part down.
- (3) To retract the writing unit, slide other lever.
- (4) Screw the small cap off to get the eraser.
- * For Just Meet, eraser is not available.



How to use the ball point pen



How to use the mechanical pencil



Replacing a used refill with a new one

Screw the barrel off. * In case of Just Meet, screw the mouth piece off and replace the refill while sliding the lever. * In case of 2+1 EVOLT SLIM, LEGNO, and RIDGE, hold the cap and pull out the barrel.	Pull the empty refill out.	Insert a new refill completely into the refill holder.	Reassemble the pen by firmly screwing the barrel. * In case of 2+1 EVOLT SLIM, LEGNO and RIDGE, put the cap back in place.

How to refill with new leads

Screw the barrel off. * In case of Just Meet, screw the mouth piece off and insert the leads while sliding the lever. * In case of 2+1 EVOLT SLIM, LEGNO and RIDGE, hold the cap and pull out the barrel.	In case of Retractable & Twist type, while seeing the mechanical pencil mark, press the cap the writing unit to come out.	In case of Shaker mechanical pencil, hold the writing unit downward and pull it off. Insert the leads from back side of the writing unit. To reassemble, put into refill holder firmly at downward position.	Hold the pen at upright position and pull the writing unit.	Insert up to three leads in total. * Putting four or more leads may cause the guide pipe to clog.	Firmly place the removed writing unit back in its original position.	Reassemble the pen by firmly screwing the barrel. * In case of 2+1 EVOLT SLIM, LEGNO and RIDGE, put the cap back in place.

Refills for ball point pens and spare leads for mechanical pencils

- Please ask specifically for PILOT BRFS-10F(ball diameter of 0.7mm), BRFS-10EF(0.5mm), BRFS-10M(1.0mm) oil-based Acro-ink ball point pen refills or BRFS-8F(0.7mm), BRFS-8EF(0.5mm), BRFS-8M(1.0mm) oil-based ink refills. For lever slide-type pens, please specify BTRF-6F(0.7mm) or BSRF-6F(0.7mm).
- Please use "PILOT NEOX GRAPHITE 0.5mm" leads. There are ten leads densities.
- * The easiest way to get the right ball point pen refill is to bring the refill that you normally use as a sample.

Remarks

- Do not use except for writing.
- Keep away from the children.
- To prevent ink leakage, never write with the pen point upwards.
- Do not give severe shocks such as dropping or hard shaking,
- as the writing unit or the pencil leads may be damaged.
- The stains on the clothes may not wash off because of permanent type of ink.
- Always retract the writing tips after use.